

EXPRESS EVENTS

WIND AT A GLANCE

A visual wind reference for event teams

0–3 mph

Leaves barely move. Smoke rises in calm air or drifts lightly.



4–7 mph

Leaves rustle. Wind is felt on your face. Weather vanes begin to turn.



8–12 mph

Leaves and small twigs keep moving. A lightweight flag extends.




13–18 mph

Small branches move. Dust and loose paper lift.
This range crosses the 15 mph cutoff.



19–24 mph

Small trees and larger branches sway.
Inflatables should already be out of use.



**AT 15 MPH OR HIGHER, INCLUDING GUSTS:
Remove all users. Follow safe shutdown and deflation instructions.**

Follow any lower equipment-specific limit. Visual estimates cannot confirm safe operation.

Simplified Beaufort wind observations • Use an onsite wind meter.

ExpressEvents.com