



SCISSOR LIFT – SAFETY INSTRUCTIONS & HOW-TO

(Genie 9.8m Marine-Safe Guidelines)

Before You Start

- Ensure the platform is clear of tools and debris.
- Make sure the lift is returned fully charged.
- Wear correct PPE: closed shoes, hi-vis, gloves.
- Only operate on **flat, stable, hardstand surfaces**.
- **Never use a scissor lift on a vessel deck** or uneven ground.

Important – Dirty Work Notification

If your job **becomes dirtier than originally booked** — such as:

- painting
- sanding
- fibreglass work
- heavy dust
- overspray
- chemical application

You must contact us immediately.

We have **specific scissor lifts dedicated to “dirty work”** to prevent damage to paint, hydraulics, electronics, and the platform.

Using a clean lift for messy work may incur cleaning or repainting fees as per your agreement.

How to Operate

1. Insert the key and turn to the **platform controls**.
2. Ensure safety rails and toe boards are securely in place.
3. Step onto the platform and close the safety gate.
4. Use the joystick to raise or lower the platform slowly.
5. Always look for overhead hazards (rigging, lights, structure).
6. Keep both feet on the platform — **no climbing rails**.

7. Lower fully before repositioning or moving the lift.

Charging the Lift

- Plug into a standard 240V outlet.
 - Confirm the charger indicator lights are active.
 - Charge overnight or throughout the day if heavily used.
 - Return the lift **fully charged**.
-

General Safety Rules

- No licence required, but operator must be competent.
- Do not exceed the **454kg platform load limit**.
- Keep wheels locked when in use.
- Never override alarms or safety switches.
- Do not use in high wind or open-shed weather conditions.

SCISSOR LIFT DISCLAIMER

The hirer accepts full responsibility for the safe and correct operation of the scissor lift at all times. Lifted Hire Pty Ltd is not liable for any damages, injuries, misuse, or incorrect operation of the equipment, including use on uneven ground, use in unsafe weather conditions, or failure to follow instructions provided.

The hirer is financially responsible for all hire charges, regardless of arrangements made between the hirer and their own clients. If you book the equipment, you are the person legally and contractually obligated to pay for it.

Any damage resulting from overspray, paint, dust, grinding residue, or other “dirty work” will be charged to the hirer unless the appropriate dirty-work lift has been booked.