



(07)5502 9082

hire@liftedhire.com.au

D5/1 Boatworks Drive, Coomera QLD 4209

www.liftedhire.com.au

ROLLING SCAFFOLDS – SAFETY INSTRUCTIONS & HOW-TO

(Small 1.7m / Medium 2.2m / Large 4m Platform Heights)

Before You Start

- Inspect frames, braces, wheels, guardrails and planks.
- Ensure all locking pins and braces are secure.
- Only use on **flat, level ground** (hardstand, shed floors).
- Wear proper PPE.

Assembly Steps

1. Lock wheels before assembling.
2. The base frame and cross braces are already in place.
3. However you can move the platform to the desired height (1.7m/2.2m/4m).
4. Do a final shake test — scaffold must feel rigid before climbing.

Using the Scaffold

- Always keep wheels locked while working.
- Only move the scaffold when **no one is on it**.
- Maintain three points of contact when climbing.
- Keep tools, cables, and hoses tidy to prevent tripping.
- Do not stand on railings or add height with ladders.

General Safety Rules

- Only use scaffolds for their intended purpose.
- Maximum platform load should not be exceeded.
- Avoid using in high wind or rain.
- Do not lean scaffolds against a boat hull or structure.

ROLLING SCAFFOLD DISCLAIMER

The hirer is fully responsible for ensuring the scaffold is assembled, secured, and used safely and correctly. Lifted Hire Pty Ltd accepts no liability for injuries or damage resulting from incorrect assembly, failure to use guardrails, failure to stabilise the scaffold, exceeding platform load limits, or moving the scaffold while occupied.

The hirer is solely responsible for payment of all hire fees, regardless of any external agreements with customers, subcontractors, or third parties. If you hire the scaffold, you are the one required to pay for it — no exceptions.

Scaffolds must only be used on flat, stable ground and must not be modified or altered. It is the hirer's responsibility to comply with all workplace safety and height-access regulations.